


Instructions for Use

Climapro

Programmable Room Thermostat

Climapro RF

Radio Controlled Programmable
Room Thermostat



General

Customer Service:

01773 828100

Technical Helpline:

01773 828300

General and Sales enquiries:

Tel. 01773 824639

Fax: 01773 820569

The instructions are an integral part of the control and must, to comply with the current issue of the Gas Safety (Installation and Use) Regulations, be handed to the user on completion of the installation.



*The code of practice for the installation,
commissioning & servicing of gas central heating*

Contents

General Information	Page
General, Documents, Application, Servicing & Recycling	4-5
Instructions for Use	
Control buttons	7
Main display	7
Description of buttons	8
Display symbols	9
Choosing the operating mode	10
Setting the Comfort temperature	11
Setting the “Eco” temperature	12
Domestic hot water temperature adjustments	13
Domestic hot water advance	14
“Holiday” function	15
Setting the day, time and date	16
Setting the 7 day central heating programme	17
Setting the 7 day DHW heating programme	20
Central Heating Temporary Override	24
Information menu	25
Battery Replacement	27
Fault finding	29

General Information

Controls Description

The Climapro is a programmable room thermostat with separate 7 day programmes for heating and hot water.

This control gives you personalised heating comfort according to your requirements and will improve the energy efficiency of your heating system.

The modulating regulation built into this thermostat changes the temperature of the radiators to suit the desired ambient temperature.

Any other use is considered as inappropriate and is forbidden.

The manufacturer will not be responsible for any damage caused by another use. In that case the user shall be responsible.

General

The installation and the commissioning of the control has to be carried out by a competent person who is responsible for the compliance of the installation and the commissioning according to current regulations.

Maintenance should be carried out by a competent person in accordance with the rules in force.

Documents

Please keep this manual as well as any documents enclosed with it safe for future reference.

We accept no liability in case of damage due to the non-compliance of the instructions of the present manual.

General Information

Cleaning

DO NOT use any abrasive cleaning products as they could damage the housing or plastic case.

Clean the case of the Climapro with damp cloth.

Make sure that no water goes inside the Climapro.

Recycling

The Climapro comprises of many recyclable parts and should be disposed of according to the current WEEE regulations.

The packaging should also be disposed of according to the current regulations.

Control Buttons




Diagram 1

Main Display

The LCD will display the following as shown in diagram 2.
(*) Display only possible if an outside sensor is connected to the boiler.



















Diagram 2

Description of Buttons

	Continuous Central Heating
	Timed Central Heating
	Eco temperature
<i>OFF</i>	Appliance OFF
	Central Heating programme
	Hot water preheat / timed hot water programme
	Domestic hot water advance (temporary override activated)
	Manual override
	Programming menu
	Installer menu
	Information menu
	Holiday mode
	Outdoor temperature and sensor
	Temperature / time period
	Day of the week
	Date / time

Display Symbols

mode Button

By pressing several times on the **mode** button, you will access the following settings, see table below.

prog Button

By pressing on the **prog** button several times you can see the different programmes.

By pressing and holding for 5 seconds you can modify the heating programme.

- Button

By pressing on the **-** button, you reduce the value of the setting.






+ Button

By pressing on the **+** button, you increase the value of the setting.

Number of presses	Description
1	Choice of operating mode
2	Heating temperature setting "Comfort"
3	Heating temperature setting "Eco"
4	Adjusting the temperature of domestic hot water
5	Domestic hot water advance
6	"Holiday" function
7	Setting the day of the current week
8	Setting the time - hours
9	Setting the time - minutes
10	Setting the date

Mode button settings

Choosing the Operating Mode


Symbol	Operating mode
	Timed: The heating will operate to the programmed on and off times  Comfort or  Eco.
	Comfort: Continuous heating on at Comfort (desired) temperature
	Eco: Heating on at Eco (minimum) temperature
<i>OFF</i>	Off: Heating is off but the domestic hot water is still operating at the set temperature.

1. To change the operating mode, press **(mode)** once.
2. Press **(+)** until the desired mode flashes.
3. The setting is saved after 10 seconds or by pressing the **(mode)** button, which will then continue to the next setting.

Setting the Comfort temperature


The comfort temperature is the temperature you require when the room is in use and the heating is on.



1. Press the **(mode)** button twice, the temperature will flash.
2. Use the **(+)** and **(-)** buttons to set the “Comfort”  temperature, min. 5°C, max. 30°C, recommended 20°C.
3. The setting is saved after 10 seconds or by pressing the **(mode)** button.

Setting the “Eco” temperature

The *ECO* temperature allows you to set the minimum temperature of the room when not in use, e.g. at night



1. From the main display, press the **(mode)** button 3 times.
2. Use the **⊕** and **⊖** buttons to set the “ECO” **☾** temperature, min. 5°C, max. 30°C, recommended 15°C.
3. The setting is saved after 10 seconds or by pressing the **(mode)** button.

Domestic hot water temperature adjustments


If you have a Glow-worm combination boiler, the domestic hot water temperature can be adjusted using the Climapro. If you have a system or open vent boiler with a domestic hot water cylinder this is controlled using the tank thermostat.



1. Press the **(mode)** button 4 times.
2. Use the **+** and **-** buttons to set the temperature of domestic hot water, min. 38°C, max. 65°C, recommended 60°C.
3. The setting is saved after 10 seconds or by pressing the **(mode)** button.

Domestic hot water advance

This function allows you to advance the timed DHW programme. This function will stay activated until the end of the following programmed DHW timed period.



1. Press the **(mode)** button 5 times: OFF is displayed.
2. Press the **(+)** button to activate DHW advance: ON is displayed.
3. The **ix** symbol is displayed.

The function is active until the end of the following programmed DHW timed period. Once the end of the programmed DHW timed period is reached the DHW advance function is switched off automatically.


To manually switch off the DHW advance function, press **(mode)** button 5 times.

From the DHW advance display press the **(-)** button.

OFF is displayed. The function is now deactivated.

“Holiday” function

The Climapro has a “Holiday” function that enables you to set the number of days you are absent. The heating will automatically come on at your return, allowing you to return to a warm house. When the control is in the “Holiday” mode, the operating mode is set to OFF and the frost protection automatically activated.



1. Press the **(mode)** button 6 times: the holiday duration setting **00** flashes for approximately 10 seconds.

2. Press the **(+)** and **(-)** buttons to select the number of days (1 to 99) during which you are absent.

The symbol **🏠** is displayed.

3. The setting is saved after 10 seconds or by pressing the **(mode)** button to continue to the next setting.

4. The function is then activated for the number of days programmed. Once the programmed duration of the holiday has been reached, the “Holiday” function **🏠** is automatically deactivated.

To deactivate the function, press once on the **(mode)** button and the symbol **🏠** will no longer be displayed.

Setting the day, time and date

Setting the current day of the week

1. Press the (mode) button 7 times.
2. Use the (+) and (-) buttons to set the current day of the week. The selected day flashes.

① = Monday	⑤ = Friday
② = Tuesday	⑥ = Saturday
③ = Wednesday	⑦ = Sunday
④ = Thursday	

Setting the time

1. Press the (mode) button 8 times.
2. Use the (+) and (-) buttons to set the current time.
3. Press the (mode) button. Use the (+) and (-) buttons to set the minutes.
4. The setting is saved after 10 seconds or by pressing the (mode) button to continue to the next setting.

NOTE: The “Yearly Calendar” will automatically switch between Summer and Winter.

Setting the date

1. Press the (mode) button 10 times.
2. Use the (+) and (-) buttons to set the current date: Day/ Month/Year.
3. The setting is saved after 10 seconds or by pressing the (mode) button.

Setting the 7 day central heating programme

The 7 day central heating programme allows you to select up to 3 “Comfort” heating timed periods for each day of the week. The control is factory set as shown in the table.

Factory setting for time periods:

Time period	Day of the week / Day groups	Start time	Stop time
[1]	① ② ③ ④ ⑤ 6 7	06:00	22:00
	1 2 3 4 5 ⑥ 7	07:30	23:30
	1 2 3 4 5 6 ⑦	07:30	22:00
[2]	-	-	-
[3]	-	-	-

The 7 day heating programme is only active in timed operating mode Ⓡ.

NOTE: If a 24 hour programme is preferred, contact the installer for further assistance.

Setting the 7 day central heating programme

Up to 3 separate time periods can be programmed in one 24hr period for different days of the week.

IMPORTANT: The three time periods must not overlap.

For example:-

Mon. to Fri. ①②③④⑤

Time period [1] Morning 5:30am - 7:00am

[2] Midday 11:00am - 1:00pm

[3] Evening 5:30pm - 10:30pm


Sat. Sun. ⑥⑦

Time period [1] Morning 10:00am - 12:00pm

[2] Evening 5:00pm - 11:00pm

[3] Not used

Setting the 7 day central heating programme



1. Press the **prog** button for approximately 5 seconds.
2. The **III** symbol flashes, press **prog** to confirm selection of central heating. The time period [1] is displayed flashing.
3. Press the **prog** button and using the **+** and **-** buttons choose the day of the week or the day groups for the selected time period according to your requirements.
4. Press the **prog** button and using the **+** and **-** buttons, choose the start time then the end time for the time period.

Full week	① ② ③ ④ ⑤ ⑥ ⑦
From Monday to Friday	① ② ③ ④ ⑤ 6 7
Week-end	1 2 3 4 5 ⑥ ⑦
For each day of the week	①, ②, ③, etc.

5. Press the **prog** button once more to programme the following time period.

Repeat the previous programming steps.

6. To exit the programming menu, press the **prog** button for approximately 10 seconds.

Setting the 7 day DHW heating programme

The domestic hot water heating programme will provide either a timed preheat function on a combination boiler, allowing a quicker response of hot water to the tap or timed hot water from a domestic hot water cylinder (system or open vent boilers).

The programme allows you to select up to 3 timed periods for each day of the week. The control is factory set as shown in the table.

Factory setting for time periods:

Time period	Day of the week / Day groups	Start time	Stop time
[1]	① ② ③ ④ ⑤ 6 7	06:00	22:00
	1 2 3 4 5 ⑥ 7	07:30	23:30
	1 2 3 4 5 6 ⑦	07:30	22:00
[2]	-	-	-
[3]	-	-	-

The programme is only active in timed operating mode ④.

NOTE: If you would like to switch to 24 hour only, rather than 7 day programming, contact a competent person.

Setting the 7 day DHW heating programme

Up to 3 separate time periods can be programmed in one 24hr period for different days of the week.

IMPORTANT: The three time periods must not overlap.

For example:-

① ② ③ ④ ⑤

Mon. to Fri.

Time period [1] Morning 5:30am - 6:30am

[2] Midday 11:00am - 12:00pm

[3] Evening 5:30pm - 8:30pm


Sat. Sun. ⑥ ⑦

Time period [1] Morning 10:00am - 12:00pm

[2] Evening 5:00pm - 9:00pm

[3] Not used

Setting the 7 day DHW heating programme



1. Press the **prog** button for approximately 5 seconds.
2. Press **+** to select the tap symbol, then press **prog**, the time period "[1]" flashes. Select the time period that you would like to programme using the **+** and **-** buttons.
3. Press the **prog** button and using the **+** and **-** buttons choose the day of the week or the day groups for the selected time period according to the table below.

Full week	①②③④⑤⑥⑦
From Monday to Friday	①②③④⑤ 6 7
Week-end	1 2 3 4 5 ⑥⑦
For each day of the week	①, ②, ③, etc.

Setting the 7 day DHW heating programme

4. Press the **prog** button and using the **+** and **-** buttons, choose the start time then the end time for the time period.


5. Press the **prog** button once more to programme the following time period.



Repeat the previous programming steps.

6. Press for approximately 10 seconds on the **prog** button to exit the programming menu.



Central Heating Temporary Override


This adjustment allows the modification of the set room temperature until the next temperature change in the heating programme.


This setting is only possible in timed operating mode .


1. From the main display, press the  or  buttons to display the set room temperature.


2. The symbol  is displayed and the previous set temperature flashes.


Press the  or  buttons to set the desired ambient room temperature, 5°C min. to 30°C max.



3. The setting is saved after 10 seconds or after pressing the  button.



At the next temperature change in the heating programme, the symbol  will no longer be displayed.

To make this setting void, press the  button and the key message *OFF* will be displayed.

The main display will refresh after 3 seconds and the symbol  will no longer be displayed.

Information menu

This function enables you to scroll through the Climapro's control menus.

Press the  button once and the symbol  will be displayed on the following menus.


Press the  button again to scroll to the next menu.

- Display of the set "Comfort" temperature value.
- Display of the set "Eco" temperature value.
- Displaying the value of the set DHW temperature.
- Display of the time zones set for the heating programme.
- Display of the date (if the function "Yearly Calendar" has been activated by your installer).
- Display of the control's commercial name.

After scrolling through the settings, leave the controller for 10 seconds and the display will revert to the main screen.

Frost protection

Frost protection will operate when:

- The ambient temperature in the room where the appliance is installed falls below 3°C.
- The outside temperature falls below 5°C (protection possible only if an outside sensor is connected to the boiler).
- The “Holiday”  function is in use (see chapter “Holiday function”).
- The control operating mode is set to *OFF*.


If the property is to be vacated for some time, please refer to the boiler literature.

NOTE: The boiler will operate out of timed periods to protect your home from frost damage and maintain the minimum (ECO) temperature.

Battery Replacement

Climapro RF only:

When “BATT” appears on the display, the battery life span is equivalent to approximately one month.




Comments:

If the batteries are not replaced in time, the boiler works without taking the room thermostat into account. Programme settings will not be lost.

- Clean the battery compartment before inserting new batteries.
- Do not mix new and used batteries of different types.
- Do not use rechargeable batteries.
- Never expose the batteries to excessive heat or a naked flame, never try to take them apart and make sure they are never short circuited.
- Do not keep the batteries in the controller. If electrolyte leaks and comes in contact with skin or clothing, rinse them immediately with water.

Battery Replacement

To replace the batteries see diagram. Remove the controller from the back box with reference to the order of operation (A) to (C), carefully replace the batteries (D) respecting the polarity (direction of “+” and “-”).




Fault finding

WARNING:

The service or repair of the control must only be undertaken by a competent person.

In the event of a fault, a message will be displayed in the multifunctional display zone, see diagram and the appropriate table overleaf.



Multifunction display zone

Fault finding


Climapro

Display	Fault	Corrective action
The display is off	Power supply failure	Check the power supply from the network. Check the power supply to your home with your provider. Check the cable and connection between control and boiler. Check that the boiler is switched on.
<i>COM Err</i>	Communication error between the boiler and Climapro	Please contact your Installation/Service company or Glow-worm service.
<i>BMU Err</i>	Boiler fault	Refer to the Fault finding section (boiler fault codes) within your Installation and servicing literature supplied with your boiler.
If any of the above faults persists, call your Installation/Service company or Glow-worm service		

Fault finding

Climapro RF

Display	Fault	Corrective action
The display is off	The batteries are not operating the appliance.	Check that: <ul style="list-style-type: none">- The batteries have not been correctly installed in their compartment. Re-install batteries in their compartment.- The polarity of the batteries is correct.- The batteries have no charge. If this is the case, replace them with new batteries. As soon as the power supply has been established, the appliance automatically turns on.
<i>BATT</i>	Battery power level low.	Replace the batteries, see section 2.15 battery replacement.
<i>COM Err</i>	Communication error between the boiler and the radio receiver.	Please contact your installer or Glow-worm service.
<i>RF Err</i>	Communication error between the radio receiver and the room thermostat.	Check that there is no power "interruption" and the boiler is connected correctly and switched on. As soon as the power supply has been re-established, the appliance automatically turns back on.
<i>BMU Err</i>	Boiler fault	Refer to the Fault finding section (boiler fault codes) within the Installation and servicing literature supplied with your boiler.
If any of the above faults persists, call your Installation/Serviceing company or Glow-worm service		



0020071550

Glow-worm
Nottingham Road, Belper, Derbyshire.
DE56 1JT

0020071550-04 06.09

Because of our constant endeavour for improvement, details may vary slightly from those shown in these instructions.